SUREMOUNT ®

SMLFT-S650, S1000 and S1300
MINIMUM AND MAXIMUM HEIGHT SETTING INSTRUCTIONS

MINIMUM HEIGHT SETTING

1. Firstly, press the 'up' button to move the tower above the height that you would like your minimum height to be.

2. Press the 'down' button to move down to the desired minimum height and press the 's' button 7 times. This will set the minimum height.

3. To cancel the minimum height, press the 'down' button to the minimum height and press the 's' button 7 times.

MAXIMUM HEIGHT SETTING

1. Firstly, press the 'down' button to move the tower down past the height that you would like the maximum height to be.

2. Press the 'up' button to move up to the desired maximum height and press the 's' button 7 times. This will set the maximum height.

3. To cancel the maximum height, press the 'up' button to the maximum height and press the 's' button 7 times.